

Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6

>TRIGGER SETUP
2 CHANNEL GRAPH
3 CHANNEL GRAPH
Y SELECTS, N EXITS GRAPHICS MODE.

Fig. 7

>ENABLE TRIGGER
DISABLE TRIGGER
EDIT TRIGGER
Y SELECTS, N EXITS GRAPHICS MODE.

Fig. 8

>A/C RELAY
SCROLL TO SELECT PARAMETER.
Y SELECTS, N EXITS GRAPHICS MODE.

Fig. 9

>A/C RELAY
>GREATER THAN
SCROLL TO SELECT TRIGGER THRESHOLD.
Y SELECTS, N EXITS GRAPHICS MODE.

Fig. 10

A/C RELAY
EQUAL TO
>ON
Y SELECTS, N EXITS GRAPHICS MODE.

Fig. 11

BATTERY (V)
LESS THAN _____
>0123456789. - DELETE DONE BACK
Y SELECTS, N EXITS GRAPHICS MODE.

Fig. 12

BATTERY (V)
LESS THAN 11.75
>TRIGGER @ LEFT CENTER RIGHT BACK
Y SELECTS, N EXITS GRAPHICS MODE.

Fig. 13

>ACCEPT
BATTERY (V)
LESS THAN 11.75 @ CENTER
Y SELECTS, N EXITS GRAPHICS MODE.

Fig. 14




Fig. 15




Fig. 16




Fig. 17




Fig. 18




Fig. 19

Setting the trigger

Fig. 20




Fig. 21 Trigger capture




Fig. 22 Trigger capture cancel

